Application for Deicing

- A suggested method is deice Low Volume areas using AquaSalina[®] or AquaSalina+[®] at 35-70 gallon/lane mile (acre) or,
- Apply rock salt to ice pack and let sit 40 minutes, treat with AquaSalina[®] or AquaSalina+[®] filling the holes surrounding the salt crystals, let sit for 40 minutes and then plow
- Apply 8-10 gallons/lane mile at spinner